









Servo Setup Pages.


Please check your setting against these and let me know where they are different











Please write down the setting that you have that are different to those on this document. Please realize that some may be different because of your particular table, but I am most curious about the settings for the Motor Signals, Mechanics, Feedrate/Ramping, and Input pages.